



## **PISTONES Y CAMISAS - KIT DE DISTRIBUCION - KIT DE DISTRIBUCION FORD TRANSIT / CITROEN RELAY / FIAT DUCA**

Kit de distribucion / Cadena de distribución / Material de distribución / Kit de cadena de distribución / Timing Chain Tensioner Kit / Timing Chain / Cadena de distribución / Juego de cadena de distri

### REFERENCIA/OEM

bk2q6m000a1a, 8052553239460 , 513C6, 514C6, 805H3, 816H4, 81826, 81827, 81828, 829E0, 9675777680, 967577848, 9675805880, 9675805980, 9677427780, 9659435180, 9659438580, 9659439880, 9659486680, 9659488680, 9659679980, 9659680180, 9659901780, 9675777680, 9675778480, 9675805880, 9675805980, 9677427780, 1116905, 1201417, 1230867, 1372426, 1372427, 1372428, 1372434, 1372437, 1372438, 1465146, 1465148, 1557881, 1576366, 1682478, 1704049, 1704066, 1704067, 1704087, 1801837, 1920072, 3S7Q6700AA, 3S7Q6700AB, 3S7Q6700AC, 6C1Q6256AB, 6C1Q6256AC, 6C1Q6306AB, 6C1Q6K261AC, 6C1Q6M256BB, BK2Q6268AA, BK2Q6306AA, BK2Q6K254AB, BK2Q6K261AA, BK2Q6M000A1A, BK2Q6M256AB, XS7Q6700AF, XS7Q6700AG, 513C6, 514C6, 805H3, 816H4, 81826, 81827, 81828, 829E0, 9675777680, 967577848, 9675805880, 9675805980, 9677427780

### REFERENCIA MOTORES

Citroën Relay II -> 250

Fiat Ducato III -> 250/290

Ford Transit MK6 -> V347/V348/V363

Ford Transit Custom -> F3/FY/FZ

Peugeot Boxer -> 250

### VEHÍCULO

Citroën Relay II, Fiat Ducato III, Ford Transit MK6, Ford Transit Custom, Peugeot Boxer

### AÑOS

Citroën Relay II -> 2006-2011

Fiat Ducato III -> 2006-2011

Ford Transit MK6 -> 2006-2014

Ford Transit Custom -> 2006-2014

Peugeot Boxer -> 2006

MOTOR

2.2 TDCI

## VEHÍCULOS COMPATIBLES

CITROËN Relay II Van (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel)

CITROËN Relay II Minibus (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel)

CITROËN Relay II Platform / Chassis (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel)

FIAT Ducato III Minibus (250, 290) (Year of Construction 07.2006 - 05.2011, 100 PS, Diesel)

FIAT Ducato III Platform / Chassis (250, 290) (Year of Construction 07.2006 - ..., 100 PS, Diesel)

FIAT Ducato III Van (250, 290) (Year of Construction 07.2006 - ..., 100 PS, Diesel)

FORD Tourneo Custom V362 Minibus (F3) (Year of Construction 04.2012 - ..., 100 - 155 PS, Diesel)

FORD Transit Mk6 Minibus (V347, V348) (Year of Construction 04.2006 - 08.2014, 85 - 140 PS, Diesel)

FORD Transit Custom V362 Minibus (F3) (Year of Construction 04.2012 - ..., 100 - 155 PS, Diesel)

FORD Transit Custom V362 Van (FY, FZ) (Year of Construction 04.2012 - ..., 100 - 155 PS, Diesel)

FORD Transit Mk6 Van (V347, V348) (Year of Construction 04.2006 - 08.2014, 85 - 140 PS, Diesel)

FORD Transit Mk6 Platform / Chassis (V347, V348) (Year of Construction 04.2006 - 08.2014, 85 - 140 PS, Diesel)

FORD Transit Mk6 Tourneo (Year of Construction 07.2006 - 08.2014, 110 - 140 PS, Diesel)

FORD Transit V363 Minibus (FAD, FBD) (Year of Construction 08.2013 - ..., 100 - 125 PS, Diesel)

FORD Transit V363 Platform / Chassis (FED, FFD) (Year of Construction 08.2013 - ..., 100 - 155 PS, Diesel)

FORD Transit V363 Van (FCD, FDD) (Year of Construction 08.2013 - ..., 100 - 155 PS, Diesel)

PEUGEOT Boxer Van (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel)

PEUGEOT Boxer Minibus (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel)

PEUGEOT Boxer Platform / Chassis (250) (Year of Construction 04.2006 - ..., 101 - 150 PS, Diesel);

